

Please read this manual carefully before operation and keep it for future reference.

# Remote Control Manual



## Advantage Series

For more information visit [www.mrcool.com](http://www.mrcool.com).

# REMOTE CONTROL SPECS

|                       |                             |
|-----------------------|-----------------------------|
| Model                 | RG51M5/(C)EU, RG51M1/EU1    |
| Rated Voltage         | 3.0V(Dry batteries Lr03 x2) |
| Transmission Distance | 8m                          |
| Environment           | 23°F~140°F                  |

# PERFORMANCE FEATURES

1. Operating Mode: AUTO COOL DRY HEAT(Cooling only model without) and FAN.
2. Timer Setting Function in 24 hours.
3. Indoor Setting Temperature Range: 62°F~86°F.
4. Full function of LCD (Liquid Crystal Display)

# REMOTE BUTTONS FEATURE BREAKDOWN




Fig. 1



For more information visit [www.mrcool.com](http://www.mrcool.com).

# REMOTE BUTTONS FEATURE BREAKDOWN

1. **TEMP Button ▼**: Push this button to decrease the indoor temperature setting in 1°F increments to 62°F.
2. **TEMP Button ▲**: Push this button to increase the indoor temperature setting in 1°F increments to 86°F.

*Note: Press and hold and buttons together for 3 seconds will alternate the temperature display between the °C & °F scale.*

3. **MODE Selection Button**: Each time the button is pressed, the operation mode is shifted in the direction of the arrow:



*Note: Please do not select HEAT mode if the machine you purchased is cooling only type. Heat mode is not supported by the cooling only appliance.*

4. **SWING Button**: Push this switch button to activate auto swing feature of the horizontal louver. Push it again to stop.
  5. **FP Button**: During the heating operation (only when the setting mode is HEAT), press this button and the unit will operate at high fan speed with the temperature automatically set to 8°C/46°F. The display window of indoor unit will display "FP". Press the buttons of ON/OFF, MODE, FAN SPEED, TEMP UP/DOWN, TIMER ON/OFF, SLEEP or FP while operating will cancel the FP function.
  6. **AIR DIRECTION Button**: Used to change the louver movement and set the desired up/down air flow direction. The louver changes 6° in angle for each press.
  7. **RESET Button**: When you press the recessed RESET button, all current settings are cancelled and the control will return to the initial settings.
  8. **FAN SPEED Button**: Used to select the Fan Speed in four steps: AUTO, LOW, MED, or HIGH. Each time the button is pressed, the fan speed mode is shifted.
  9. **ON/OFF Button**: Push this button to start operation, push the button again to stop operation.
  10. **TIMER ON Button**: Press this button to initiate the auto-on time sequence. Each press will increase the auto-timed setting in 30 minutes increments. When the setting time displays 10h, each press will increase the auto-timed setting 60 minutes increments. To cancel the auto-timed program, simply adjust the auto-on time to 0.0.
  11. **SLEEP Button**: Press this button to go into the Energy-Saving operation mode. Press it again to cancel. This function is only can be used on COOL, HEAT and AUTO mode and maintain the most comfortable temperature for you.
- NOTE: While the unit is running under SLEEP operation mode, it would be canceled if you press the MODE, FAN SPEED or ON/OFF button.*

# REMOTE BUTTONS FEATURE BREAKDOWN

- TIMER OFF Button:** Press this button to initiate the auto-off time sequence. Each press will increase the auto-timed setting in 30 minutes increments. When the setting time displays 10h, each press will increase the auto-timed setting 60 minutes increments. To cancel the auto-timed program, simply adjust the auto-off time to 0.0
- LOCK Button:** When you press the recessed LOCK button, all current settings are locked in and the remote controller does not accept any operation except that of the LOCK. Press again to cancel the LOCK mode.
- TURBO Button:** Active/Disable Turbo function. Turbo function enables the unit to reach the preset temperature at cooling or heating operation in the shortest time(if the indoor unit has no this function, there is no corresponding operation happened when press Turbo button.)
- LED DISPLAY Button:** Press this button to clear the digit display in the air conditioner, press it again to illuminate (Not available for the units without LED display window).

# DISPLAY SCREEN BREAKDOWN




Fig. 2

- DIGITAL DISPLAY area:** This area will show the set temperature and, if in the TIMER mode, will show the ON and OFF settings of the TIMER. If in the FAN mode, nothing is appeared.
- TRANSMISSION Indicator:** This indicator flashes one time when remote controller transmits signals to the indoor unit.
- ON/OFF Indicator:** This symbol appears when the unit is turned on by the remote controller, and disappear when the unit is turned off.
- OPERATION MODE Indicator:** When press the MODE button, it shows the current operating mode: AUTO, COOL, DRY, HEAT (Cooling only model without), or FAN mode.
- LOCK Indicator:** LOCK display is displayed by pushing the LOCK button. Push the LOCK button to clear display.

## DISPLAY SCREEN BREAKDOWN

6. **TIMER DISPLAY Indicator:** This display area shows the settings of the TIMER. That is, if only the starting time of operation is set, it will display the TIMER ON. If only the turning off time of operation is set, it will display the TIMER OFF. If both operations are set, it will show TIMER ON-OFF which indicates you have chosen to set both the starting time and off time.

7. **FAN SPEED Indicator:** Press the FAN SPEED button to select the desired fan speed setting (Auto-Low-Med-High). Your selection will be displayed in the LCD window except the Auto fan speed.

**NOTE:** All signs shown in the Fig.2 is for the purpose of clear presentation. But during the actual operation only the relative functional signs are shown on the display panel.

## OPERATING THE REMOTE

### 🔑 Install/Replace Batteries

The Remote Controller uses two alkaline dry batteries(LR03X2).

1. To install the batteries, slide the back cover of the battery compartment and install the batteries according to the direction (+and -)shown on the Remote Controller.
2. To replace the old batteries, use the same method as mentioned above.

#### **Note:**

1. When replacing batteries, do not use old batteries or a different type battery. This may cause the remote control to malfunction.
2. If you do not use the remote controller for several weeks remove the batteries. Otherwise battery leakage may damage the remote controller.
3. The average battery life under normal use is about 6 months.
4. Replace the batteries when there is no answering beep from the indoor unit or if the Transmission Indicator light fails to light.
5. Do not dispose batteries as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

### 🔑 Install/Replace Batteries

Switch on the power and the OPERATION indication lamp on the display panel of the indoor unit starts flashing, and turns off after flashes for 6 times.

1. Use the MODE button to select AUTO.
2. Push the TEMP button to set the desired temperature within a range of 62°F ~ 86°F.
3. Push the ON/OFF button to start the air conditioner. The OPERATION lamp on the display panel of the indoor unit lights. The FAN SPEED is automatically set and there are no fan speed indicators shown on the display panel of the remote controller.
4. Push the ON/OFF button again to stop the unit operation.

# OPERATING THE REMOTE

## **AUTOMATIC OPERATION**

Switch on the power and the OPERATION indication lamp on the display panel of the indoor unit starts flashing, and turns off after flashes for 6 times.

1. Use the MODE button to select AUTO.
2. Push the TEMP button to set the desired temperature within a range of 62°F ~ 86°F.
3. Push the ON/OFF button to start the air conditioner. The OPERATION lamp on the display panel of the indoor unit lights. The FAN SPEED is automatically set and there are no fan speed indicators shown on the display panel of the remote controller.
4. Push the ON/OFF button again to stop the unit operation.

### **NOTE:**

1. In the AUTO mode, the air conditioner can logically choose the mode of COOL, FAN and HEAT by sensing the difference between the actual ambient room temperature and the set temperature on the remote controller.
2. If the AUTO mode is not comfortable for you, the desired mode can be selected manually.

## **COOL/ HEAT (Cooling only model without) and FAN Operation**

1. If the AUTO mode is not comfortable, you may manually over-ride the settings by using COOL, HEAT or FAN modes.
2. Push the TEMP button to set the desired temperature within a range of 62°F ~ 86°F.
3. Push the FAN SPEED to select the FAN mode of AUTO, HIGH, MED, or LOW.
4. Push the ON/OFF button, the operation lamp lights and the air conditioner start to operate as your settings. Push the ON/OFF button again to stop this unit operation.

**Note:** The FAN mode can not be used to control the temperature. While in this mode, only steps 1, 3, and 4 may be performed.

## **DRY Operation**

1. Push the MODE button to select DRY.
2. Push the TEMP button to set the desired temperature within a range of 62°F ~ 86°F.
3. Push the ON/OFF button, the OPERATION lamp lights and the air conditioner starts to operate in DRY mode at LOW fan speed. Push the ON/OFF button again to stop this unit operation.

**Note:** Due to the difference of the set temperature of the unit and the actual indoor temperature, the Air Conditioner when in DRY mode will automatically operate many times without running the COOL and FAN mode.

## **TIMER Operation**

Push **TIMER ON** button to set the auto-on time and **TIMER OFF** button to set the auto-off time.

### **1. To set the starting time.**

1.1 Push the **TIMER ON** button, then the remote controller shows **TIMER ON**, the last set time for the starting operation and the signal "h" will be shown on the **DIGITAL DISPLAY** area. You are now ready to reset the time to **START** the operation.

1.2 Push the **TIMER ON** button again to set desired unit start time.

1.3 After setting the **TIMER ON**, there will be a one-half second delay before the remote controller transmits the signal to the air conditioner. Then, after approximately another 2 seconds, the signal "h" disappears and the set temperature will re-appear on the digital display.

### **2. To set the stopping time.**

2.3 After setting the **TIMER OFF**, there will be a one-half second delay before the remote controller transmits the signal to the air conditioner. Then, after approximately another 2 seconds, the signal "h" disappears and the set temperature will re-appear on the digital display.

2.2 Push the **TIMER OFF** button again to set the time you want to stop the operation.

2.1 Push the **TIMER OFF** button and the remote controller will show **TIMER OFF**, the last set time for the stopping operation and the signal "h" will be shown on the **DIGITAL DISPLAY** area. You are now ready to reset the time of the **STOP** operation.

### **3. Set the starting & stopping time**

3.1 Push the **TIMER ON** button, the remote controller will show **TIMER ON**, the last set time for **START** operation and the signal "h" will be shown on the **DIGITAL** display area. You are now ready to readjust the **TIMER ON** to start the operation.

3.2 Push the **TIMER ON** button again to set the time you want to start the operation.

3.3 Push the **TIMER OFF** button, the remote controller will show **TIMER OFF**, the last set time for **STOP** operation and the signal "h" will be shown on the **DIGITAL** display area. You are now ready to reset the time to **STOP** operation.

3.4 Push the **TIMER OFF** button again to set the time you want to stop the operation.

3.5 After setting the **TIMER**, there will be a one-half second delay before the remote controller transmits the signal to the Air Conditioner. Then, after approximately another 2 seconds, the signal "h" disappears and the set temperature will re-appear on the digital display.

## **Change the TIMER**

- To change the **TIMER ON/OFF** time, just press the corresponding **TIMER** button and reset the time.

- To cancel the **TIMER ON/OFF** setting, just adjust the **TIMER** time to 0.0.

*NOTE: The setting time is relative time. That is the time set is based on the delay of the current time.*

## NOTICE

1. Be sure there are no obstacles between the remote controller and the receiver of indoor unit otherwise the air conditioner will not work.
2. Keep the Remote Controller away from any liquids.
3. Protect the remote controller from the high temperatures and exposure to radiation.
4. Keep the indoor receiver out of direct sunlight or the Air Conditioner may malfunction.
5. Keep Remote Controller away from EMI(Electro-Magnetic Interference) supplied by other household appliances.

### **NOTE:**

*The device could comply with the local national regulations. In Canada, it should comply with CAN ICES-3(B)/NMB-3(B). In USA, this device complies with part 15 of the FCC Rules.*

*Operation is subject to the following two conditions:*

- (1) This device may not cause harmful interference, and*
- (2) this device must accept any interference received, including interference that may cause undesired operation.*

*This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:*

- Reorient or relocate the receiving antenna.*
- Increase the separation between the equipment and receiver.*
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- Consult the dealer or an experienced radio/TV technician for help.*
- Changes or modifications not approved by the party responsible for compliance could void users authority to operate the equipment.*



# Advantage Series

The design and specifications are subject to change without prior notice. Consult with the sales agency or manufacturer for details.

For more information visit [www.mrcool.com](http://www.mrcool.com).